

60cm 4 zone PowerReady, a low current enabled induction cooktop, makes upgrading easy. It comes with Bridge zone, Hob2Hood, and PowerBoost.

RRP AUS \$1,349.00



Product Details

FEATURES

PowerReady connects to standard household power

Bridge function

PowerBoost

Hob2Hood

Touch and slide controls
Touch the control bar at the necessary heat setting

Residual heat indicators all zones
Indicates which area is too hot to comfortably touch.

Pause function

Timer and minute minder

Child lock

BENEFITS

3 YEAR WARRANTY

Because peace of mind should last as long as great design, this product has three years of trusted Electrolux support.

*Available for purchases after 1 March 2026.

EFFORTLESSLY SWITCH TO INDUCTION

Enjoy the speed and precision of induction, without upgrading your homes power.* PowerReady cooktops deliver instant heat and can be connected to standard household power. *For installation please consult a licenced electrician

COMBINE ZONES FOR MORE FLAVOUR

The Bridge function allows you to combine two separate cooking zones to create a single large surface. With the temperature and time settings automatically aligned, its ideal for making the most of planchas or roasting pots.

SEAR. STIR-FRY. BOIL.

The PowerBoost function gives you an intense heat boost when needed, before automatically dropping to the highest power level. Perfect for pan searing fish, stir-frying crunchy vegetables, or bringing water to the boil quickly.

HANDS-FREE HOOD

Hob2Hood automatically switches on your extractor hood when you start cooking and adjusts the fan speed based on how you are using your hob. This means you can boil, sear or stir-fry without having to touch your hood with greasy fingers.

INTUITIVE TOUCH CONTROLS

Sensitive touch controls take you from simmering to boiling and back again, almost instantly. This controllability allows you to apply precise changes that can take your dishes from tasty to truly delicious. Pan-sear steak with intense heat, and then instantly drop the temperature down to protect that beautifully juicy, medium-rare texture.

ONE TOUCH TO PAUSE

The pause function is handy if you're suddenly interrupted or must leave the kitchen momentarily. At the touch of a button all cooking zones will be reduced to the lowest heat setting to ensure dishes stay warm, but don't overcook.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	3
Cooktop type	induction
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No
Wok included designed to fit cooktop	No

CONTROLS

Controls of Cooktops	Touch and Slide controls
Position of controls	front
Functions of Cooktops	timer,automatic switch off,Hob2Hood,PowerBoost,pause,Bridging
Indicators/display	3 level residual heat indicator
Features of Cooktop	safety cut off,minute minder,function lock,pot sensors,Hob2Hood,Bridge zone,safety child lock

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	590
Total product depth (mm)	520
Cut out width (mm)	560
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	Bridge
Left front Watts	2300
Left front boost watts	3200
Left front diameter mm	210

CONTROLS

Timer of Cooktop	auto off,Minute minder
------------------	------------------------

LEFT REAR ZONE

Left rear zone	Bridge
Left rear watts	2300
Left rear diameter mm	210

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800
Right rear diameter mm	180

SHIPPING

Shipping Volume (m3)	0.048
Shipping Weight (Kg)	11.3
Pack Dimensions Height (mm)	118

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400
Right front diameter mm	145

ELECTRICAL SPECIFICATIONS

Connected load KW	4.6
Maximum current rating (amps)	20
Type of connection	hardwired


SHIPPING

Pack Dimension Width (mm)	680
------------------------------	-----

Pack Dimension Depth (mm)	600
------------------------------	-----

Dimensions

Model:
EHI6454BF



© 2026 Electrolux S.E.A. PTE. LTD. ELX_IM_Diag_EHI6454BF_Mar26

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz