

WSF6602WC

60cm freestanding dishwasher, white, with 14 place settings, 6 wash programs including Fast 30' and Auto programs, FastDry system, half load option, adjustable upper basket and 47dB operation.

Features

- 14 place settings
- Auto mode
- FastDry
- Fast wash options
- Gentle Wash
- Delay Start - 3, 6 & 9 hours
- Half load option
- Height adjustable upper basket
- AquaStop




Dimensions


Total height (mm) - 845, Total width (mm) - 598, Total depth (mm) - 598, Height adjustment (mm) - 20

Freestanding Dishwasher

WSF6602WC / WSF6602XC
WSF6604XC
WSF6606KC / WSF6606XC
WSF6608KC / XC



	Width	Height	Depth 1	Depth 2
Cut out (mm)	600	850	580	-
Product (mm)	598	845	598	1176



IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm).
For complete installation instructions, refer to the manual provided with product.
© 2020 Electrolux Home Products Pty Ltd. ABB101 004 702 040: WSH6_6A_06p_Freestanding_Dishwasher_Aug20